


WingSpan Wall Stand Off Instructions

**Little
Giant**
Ladder Systems



1. Place arm into the rung bracket while pushing in on the locking pin. Slide arm into bracket until the locking pin engages in to the hole.




2. Repeat the first instructions for the second arm.




3. Place the WingSpan on the top rung of the ladder when the ladder is in extension position only. Make sure the WingSpan is centered securely on the top



4. Swing the clamp into the front slot of the bracket so that the clamp is facing downwards. An adjustment of the clamp may be necessary to insert clamp into the front slot.



5. This is how the WingSpan should look after you have assembled it.



A. Rung Bracket
B. Arm Assembly Including Feet(2)
C. Rubber Foot (2)

Part No.
53196
21093
51243

Little Giant Ladder Systems Toll Free: 800-453-1192
1198 N. Spring Creek Place Phone: 801-489-3684
Springville, UT 84663 Fax: 801-489-3685

www.littlegiantladders.com
©2010 Little Giant Ladder Systems PN: 51246 V3